

VINYL PLASTIC REPAIR KIT

INSTRUCTIONS

- 1. Cut to required size depending upon hole or puncture.**
- 2. Thoroughly clean damaged surface and allow to dry for a minimum of 10 minutes.**
- 3. Remove vinyl patch from paper backing.**
- 4. Press patch firmly over hole or puncture**
- 5. Do not inflate for 20 minutes.**