



TEENAGE MUTANT NINJA TURTLES®

RAZOR JET INSTRUCTIONS:

To load launching disk, turn vehicle over and insert disk as shown. Then wind by turning the disk clockwise 2 full turns as shown. Do not overwind!




1.




To activate Turbo jets, first push them into engine ports until they click into place as shown.

2.





Then press down on small stabilizer fin to make them emerge as shown.

Front fork is adjustable - you can move it up or down as shown.



Both side wings are adjustable - you can move the wing arms up or down as well as position the wings up or down.



To launch disk, press large stabilizer fin as shown. Disk will shoot downwards.

Age 4 and up

Playmates®

ASST. NO. 154150
STOCK NO. 154154

Do not use projectile other than those provided by the toy.

Teenage Mutant Ninja Turtles® © 2003 Mirage Studios, Inc. Teenage Mutant Ninja Turtles®, Leonardo®, Michelangelo®, Raphael®, Donatello®, Splinter®, Shredder®, and Foot Soldier™ are registered trademarks of Mirage Studios, Inc. All Rights Reserved. PRINTED IN CHINA.