

nickelodeon™ TEENAGE MUTANT NINJA TURTLES™




SHELL FLYER

WARNING:
CHOKING HAZARD- Small parts.
Not for Children under 3 years.

For more detailed instruction information visit
www.Playmatestoy.com
Figure sold separately.


I. Assembly:

Assemble parts
as shown.





II. Labels:

Attach labels as shown.



III. Features:

1. Place figure into
the Shell Flyer.



2. Squeeze the
lever to open
and close the
barrel claw.



3. Grab figure
to fly it high
in the sky.

Playmates
TOYS

Ages 4 and up
Asst. #94045 / #94050
Item #94072